

Destroy this report when no longer needed. Do not return it to the originator.

The findings in this report are not to be construed as an official Department of the Army position unless so designated by other authorized documents.

This program is furnished by the Government and is accepted and used by the recipient with the express understanding that the United States Government makes no warranties, expressed or implied, concerning the accuracy, completeness, reliability, usability, or suitability for any particular purpose of the information and data contained in this program or furnished in connection therewith, and the United States shall be under no liability whatsoever to any person by reason of any use made thereof. The program belongs to the Government. Therefore, the recipient further agrees not to assert any proprietary rights therein or to represent this program to anyone as other than a Government program.

The contents of this report are not to be used for advertising, publication, or promotional purposes. Citation of trade names does not constitute an official endorsement or approval of the use of such commercial products.

## REPORT DOCUMENTATION PAGE

Form Approved
OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA. 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503

1. AGENCY USE ONLY (Leave bla	· · · · · · · · · · · · · · · · · · ·	3. REPORT TYPE AND DATE	COVERED
	April 1991	Final report	
4. TITLE AND SUBTITLE			DING NUMBERS
	ation Programs for CA	ADD (Computer-	
Aided Design and Dra	arting) Systems		
6. AUTHOR(S)			
	:		
7. PERFORMING ORGANIZATION N			FORMING ORGANIZATION ORT NUMBER
	riment Station, Info ry, 3909 Halls Ferry	IMACION	scellaneous Paper
Vicksburg, MS 39180			91-2
viewobarg, no 3,100			
9. SPONSORING / MONITORING AG	ENCY NAME(S) AND ADDRESS(E	s) 10. SPC	NSORING / MONITORING
		AGI	ENCY REPORT NUMBER
11. SUPPLEMENTARY NOTES			,
	ional Technical Info	rmation Service, 5285	Port Royal Road,
Springfield, VA 2	2161.	,	
		<u> </u>	
12a. DISTRIBUTION / AVAILABILITY	STATEMENT	12b. Di	STRIBUTION CODE
Approved for public	c release; distribut:	ion unlimited	
		[	ĺ
		1	i
13. ABSTRACT (Maximum 200 word	ds)		
		ns for the geotechnica	
		log data and other geo	
		system. The program i	
collection of rout	ines for data entry,	editing, and reporting	this coftware must
be excitable for the	package is written in	n dBase III Plus and t e. Unit II is a Borir	ng Log Plotting
		h the boring log datab	
		ogs. The package extr	
horing logs and dis	solavs them in a des	ign file either singly	or in a de-
		brary and matrix menu.	
		in the CADD Standards	
		nd easy way to generat	
		t details. Instruction	
tion, use, and main	ntenance of these pag	ckages are included in	n the individual
units.			ľ
14 CURISCY TERRAS	<del></del>		15. NUMBER OF PAGES
14. SUBJECT TERMS	occina		
BoringsData proce PavementsData pro	*·		16. PRICE CODE
ravementsbata pro	oceasing,		
	18. SECURITY CLASSIFICATION	19. SECURITY CLASSIFICATION	20. LIMITATION OF ABSTRACT
OF REPORT	OF THIS PAGE	OF ABSTRACT	1
UNCLASSIFIED	UNCLASSIFIED		

#### DEPARTMENT OF THE ARMY

REPLY TO ATTENTION OF

WATERWAYS EXPERIMENT STATION. CORPS OF ENGINEERS 3909 HALLS FERRY ROAD VICKSBURG, MISSISSIPPI 39180-6199

CEWES-IM-DA

14 September 1990

MEMORANDUM THRU Chiefs, Engineering Division

FOR Chiefs, Geotechnical Branch

Subject: dBase and CADD Boring Log Programs

- 1. Enclosed is a Lessons Learned Report presenting three programs for the geotechnical engineer for the management and presentation of boring log data and other geotechnical details. These packages are presented jointly by the Computer Application in Geotechnical Engineering (CAGE) Computer-Aided Design and Drafting (CADD) Support Task Group and the CADD Center Geotechnical Single Discipline Task Group (SDTG). Much of the coordination for this document was performed by Mr. Earl Edris, principal investigator for CAGE and chairman of the Geotechnical CADD SDTG.
- 2. Unit I contains a boring log database system developed by the Vicksburg District under the direction of Mr. Chris Dixon and Mr. Ed Templeton. The program is a menu-driven collection of routines for data entry, editing, and reporting of boring log information. The package is written in dBase III Plus and this software must be available for the program to operate.
- 3. Unit II is a Boring Log Plotting program which works in conjunction with the boring log database to generate CADD design files for display of the logs. The package extracts user-defined boring logs and displays them in a design file either singly or in a definable matrix.
- 4. Unit III is a cell library and matrix menu developed by Seattle District under the direction of Mr. Steve Meyerholtz through funding by both the CAGE and CADD Task Groups. The cells used in the matrix menu are those contained in the CADD Standards Manual. This system offers a quick and easy way to generate geotechnical details such as boring log and pavement details.
- 5. Instructions for installation, use, and maintenance of these packages are included in the individual units. If you have any questions please contact Earl Edris, 601/634-3378, or Al Williamson, 601/634-2468.

CARL S. STEPHENS, PE

Chief, Computer-Aided Design

and Drafting Center



## COMPUTER-AIDED DESIGN and DRAFTING (CADD) CENTER



To enable the Corps of Engineers to achieve the best use of CADD within the shortest time frame.

The CADD Center is the Corps vehicle for sharing information and development work and minimizing duplication of effort while retaining local automonies and decentralized organizational structures.

The Center is an end-user driven, technology transfer oriented organization. Single-Discipline Task Groups (SDTG) and Special Advisory Task Groups (SATG) are formed under headquarters guidance to get field office grass roots input into CADD activities. A Field Technical Advisory Group (FTAG) provides the guidance to the Center.


To integrate and implement CADD by:

- Furnishing technical advice Conducting training
- Evaluating products
- Providing advisory teams

- Initiating studies
- Promoting communications
- Distributing products

#### **ORGANIZATIONAL CHART**

#### **FUNCTIONAL CHART**



FTAG - FIELD TECHNICAL ADVISORY GROUP

SDTG - SINGLE DISCIPLINE TASK GROUP

SATG - SPECIAL ADVISORY TASK GROUP

#### **CADD** Center **Points of Contact**

**CEWES-IM-Z** Information Technology Laboratory Chief, Dr. N. Radhakrishnan (601) 634-2527 **CEWES-IM-D** Computer-Aided Engineering Division (601) 634-4020 Chief, Dr. Ed Middleton **CEWES-IM-DA CADD Center** Chief, Mr. Sandy Stephens (601) 634-2945 CPT. Robert Felix (601) 634-2799 (601) 634-3138 Mr. Toby Wilson (601) 634-3604 Mr. John Hood (601) 634-3509 Mr. Steven Hatton Mr. Richard Bradley (601) 634-2286

"GUIDED BY THE FIELD"



US Army Corps of Engineers **CADD Center** Information Technology Laboratory Waterways Experiment Station 3909 Halls Ferry Road Vicksburg, Mississippi 39180-6199

Office Symbol: CEWES-IM-DA Ontyme: CEWES-IM-DA (601) 634-4109 1-800-LAB-6WES FAX (601) 634-2638



#### **PREFACE**

This document describes methods available to the geotechnical engineer for the production of boring log and other geotechnical details on computer-aided design and drafting (CADD) equipment. It contains all the required documentation and electronic data required to develop, maintain and display boring log information.

The boring log data base programs were developed by the Vicksburg District Corps of Engineers through a contractor funded by the District. A special thanks is given to the District and Mr. Ed Templeton and Mr. Chris Dixon for their efforts leading to successful completion of this project.

The geotechnical matrix menus were developed by the Seattle District Corps of Engineers under the direction of Mr. Steve Meyerholtz through funding by the Computer Application in Geotechnical Engineering (CAGE) project and Geotechnical Single Discipline Task Group (SDTG). A special thanks to the Seattle District and Mr. Meyerholtz.

A very special thanks is given to Mr. Earl Edris, Soil and Rock Mechanics Division, Geotechnical Laboratory, USAE Waterways Experiment Station (USAEWES). Mr. Edris is the chairman of both CAGE and the Geotechnical SDTG's. He has coordinated and provided substantial input for both of these programs and production of this report.

This report was prepared by Mr. Steven D. Hatton, under the direction of Dr. Edward E. Middleton, Chief, Computer Aided Engineering Division and Mr. Carl S. Stephens, Chief, CADD Center, Information Technology Laboratory (ITL) US Army Engineer Waterways Experiment Station (WES). General supervision was provided by Dr. N. Radhakrishnan and Mr. Paul K. Senter, Chief and Assistant Chief, ITL, respectively.

Commander and Director of WES during the conduct of this work and preparation of this report was COL Larry B. Fulton, EN. Dr. Robert W. Whalin was Technical Director.

			•
Acuts a	1 10:		
NES (		J	:
			1
tur on Justila			
Sy Distrib.	1.30./		
٠			
Dist	F. 1. Cp. 30	. :	
A-1			

# UNIT I BORING LOG DATABASE SYSTEM

#### TABLE OF CONTENTS

OVERVIEW	5
HARDWARE/SOFTWARE REQUIREMENTS	5
STARTUP PROCEDURE	5
GENERAL OPERATION	6
RUNNING THE PROGRAM	6
MAIN MENU	7
OPTION 1 - ADD A NEW BORING	8
OPTION 2 - CHANGE AN EXISTING BORING	9
OPTION 3 - ADD OR MODIFY SAMPLE FOR AN EXISTING BORING	9
OPTION 4 - PRINT BORING/SAMPLE	13
OPTION 5 - LIST EXISTING BORINGS TO SCREEN	13
OPTION 6 - DISPLAY BORING/SAMPLES	13
OPTION 7 - CREATE NEW BORING DATABASE	15
OPTION 8 - GENERATE PLOT FILES	16
OPTION 9 - MISCELLANEOUS	19
OPTION 0 - VALIDATE DATABASE	20
BACKING UP THE DATABASE	20
FORMATTING NEW DISKETTES	21

#### APPENDIXES

APPENDIX A	DATABASE STRUCTURES
APPENDIX B	VALID CODES
вз	ROCK CLASSIFICATIONS COLOR and CONSISTENCY SOIL CLASSIFICATIONS
APPENDIX C	LABORATORY LOG
APPENDIX D	WATER CONTENT
APPENDIX E	VALIDATION ERRORS (example)
APPENDIX F	TECHNICAL DOCUMENTATION
APPENDIX G	PLOT DATA FILE FORMAT
CODE LISTINGS	
BORING.PRG BORBADD.PRG BORBADD.PRG BORSADD.PRG ADDMENU.PRG ADDMENU.PRG COL_WIN.PRG ROC_WIN.PRG SOIL_WIN.PRG MOD_WIN.PRG CONS_WIN.PRG BORPRINT.PRG BORPRINT.PRG BORSCR.PRG DETOUR.PRG BORPLOT.PRG PLOTIT.PRG PLOTITLE.PRG GRADLAB.PRG WATCONT.PRG BOREDIT.PRG BOREDIT.PRG BOREDIT.PRG	

#### OVERVIEW

The Boring Log Database System is a menu driven collection of routines providing data entry, editing, reporting, and plot file generation capabilities. The routines are written in dBase III Plus. Boring Log data are input in the soils lab as samples arrive. Information about each log is entered and then data for each sample in that log. It is not necessary to enter all information requested as the samples arrive. The user may store tare numbers and wet weight and later generate gradation form labels and compute water content. As test results are available each sample or log record may be retrieved and edited. Lab log report forms may be generated for each log. When all information for a project has been entered into a database, the analytical section may then generate plot files to be transferred to the Harris.

#### HARDWARE/SOFTWARE REQUIREMENTS

IBM PC/AT compatible with hard disk drive 640k memory color graphics monitor dot matrix printer 1200 baud modem dBase III software communications package (CrossTalk, etc.)

#### STARTUP PROCEDURE

Make sure that the DOS, dBase, and Crosstalk subdirectories are in your path.

Copy the Boring Log Dababase System into the subdirectory you desire to work in.

Make this directory your current directory.

This directory is also the directory that will contain your databases.

Start dBase and enter the command "DO BORING".

A "Boring Log Boot diskette" is available that performs the above.

#### GENERAL OPERATION

Type in information requested. Generally a boring number and/or sample number is required to add, edit or display data. Enter a blank to return to the previous menu. To accept information currently displayed in a field just press return. Numbers are automatically right justified.

#### SPECIAL KEYS:

page down backspace delete home end enter

up arrow, down arrow move to the previous or next field to quit entering data on a screen delete previous character delete current character move to beginning of current field move to end of word or current field move to next field

Data entered is either numeric (strictly numbers); alphanumeric (numbers and letters); or logical (true or false). See pages A-1 for boring data and A-2 for sample data. For valid codes for soils, consistency, rocks, colors and drilling types, see Appendix B. All dates should be entered in the format: nn MON yy (i.e. 23 JUL 87).

RUNNING THE PROGRAM

DO EORING

| BORING LOG INPUT SYSTEM | \_\_\_\_\_\_

07/20/87

Enter database file name: newfile

The file name you choose must be 7 characters or less. It is suggested that the name relate to the project you are working on. If the database does not exist the user will be asked if he wants to create it.

> File does not exist! Do you wish to create a new database (y/n) ? y

At this point the program generates the necessary files and returns to the above prompt. To begin entering data into the new database, press ENTER at this time.

Enter Project: NEW PROJECT

If the project is not currently defined, the user will be asked to provide pertinent information about it.

This project is not in the database.

Do you wish to add this project ? y

Enter latitude of project site reference point: Degrees: 0 Minutes: 0 Seconds: 0.000

Enter Longitude of project site reference point: Degrees: 0 Minutes: 0 Seconds: 0.000

If you don't know the latitude and longitude of the project, just press return and skip through the fields.

Now you are into the system using a specified database. The Main Menu is displayed on the screen. The project you specified will be the default project name in all borings you enter. You may change projects on different borings if so desired, but this is not generally recommended.

MAIN MENU

CHOOSE AN OPTION --> \_\_\_

## BORING LOG INPUT SYSTEM OPTIONS

1 -	ADD A NEW BORING	6 - DISPLAY BORING/SAMPLES
2 -	CHANGE AN EXISTING BORING	7 - CREATE NEW BORING DATABASE
3 -	ADD OR MODIFY SAMPLE FOR AN EXISTING BORING	8 - GENERATE PLOT FILES
4 –	PRINT BORING/SAMPLE	9 - MISCELLANEOUS
5 -	LIST EXISTING BORINGS TO SCREEN	0 - VALIDATE DATABASE
	O - EXIT THIS PRO	CRAM

#### OPTION 1 - ADD A NEW BORING

To add a boring to the database choose Option 1, when the following screen appears type in the assigned boring log number and press return. The system will not allow entry of duplicate boring numbers. A message to that effect will appear on the screen. After pressing return, the user may enter another number. Some of the valid abbreviations for drilling method are listed at the bottom of the screen. See Appendix B for other codes. Note that the current default project automatically is displayed. Simply press ENTER to accept it or you may change the project by typing over it. When you are finished entering information about a boring, either press the Page Down key or press return to skip through the remaining fields.

Boring No. TC-22-87U								
Location	Tertiary Depth 0.0							
Date Taken	Water Table Date Water Table Depth 0.0							
Project TOWN CREEK	Method of Drilling							
G. S. Elevation 0.0	General Samples Undisturbed Samples							
Classifier Recorder Checker	North/South Location 0.00 East/West Location 0.00							
Field Book No.	Date Analysed Date Checked							
Remark								
M - Rotary Mud RNM - Rotary without Mud T4 - 1" Fishtail D25 - 2.5" Drive Tube T6 - 6" Fishtail VST - Vacuum Shelby Tube	DEN - Denison RRB - Rock Bit							

### OPTION 2 - CHANGE AN EXISTING BORING

To change an existing boring, enter the boring number. This will call up information previously entered on this boring. If the boring is not in the database, a message will appear and the user may try a different number. Once the boring input form is displayed on the screen, the user must choose to either modify or delete the boring or return to the main menu. If the user chooses to delete the boring, ALL SAMPLE DATA ASSOCIATED WITH THAT BORING WILL BE DELETED! If the user chooses to modify the boring, he may modify any field by using the up and down arrow keys to move between fields. Only the boring id may not be changed.

ocation 6' FROM TOP BK	Tertiary Depth 0.0
Date Taken 16 Jun 87	Water Table Date 16 Jun 87 Water Table Depth 25.0
Project TOWN CREEK G. S. Elevation 313.7	Method of Drilling RM General Samples D25 Undisturbed Samples VST
Classifier Recorder Checker JDC BB BB	North/South Location 0.00 East/West Location 0.00
Field Book No. 7228	Date Analysed 15 Jun 87 Date Checked 26 Jun 87
Remark	

OPTION 3 - ADD OR MODIFY SAMPLE FOR AN EXISTING BORING

To add sample data, the boring record must have previously been entered into the database. Type in the boring number and the program will ask for a sample number. The format of the sample number is 3 digits + 1 digit + 1 digit. The first three digits are a number or NSN (no sample number); the letter "A" in the next digit indicates an undisturbed sample; the last digit is used to sequence rock notes with the first being "A", second "B", and so on.

The current boring is

Type a carriage return to accept it or enter the name of the desired boring.

No. U Rock

Sample Number:

Enter blanks to return to menu.

The sample data input screen is displayed below along with descriptions of valid inputs.

Project: Boring Nu	TOWN mber:	CREEK TC-1-87	7 U			ample N Scratch		1	
SAMPL FROM	TO	WATER CONTENT	WET WEIGHT	STRATUM CHANGE	SYM	ROC	MOD TA	RAD. ARE	
	TE	SIS- NCY	COLO		MODIFICATION SYMBOLS			÷	
BLOWS PER FOOT	UCT	ATTEI LL	RBERG PL 1	D10 SIZE		WATER TENT	SECONI UCT	TESTS ASSIGNED	
COMMENTS:	. P.1								
	· · · · · · · · · · · · · · · · · · ·			N> for CO					

SCRATCHED - either T or F, indicates whether or not that sample is to be used in the plot routines.

SAMPLE FROM and TO - beginning and ending depths of sample.

WATER CONTENT - if preceded by a letter (M24) indicates a tare number and you should enter a WET WEIGHT. Later the user may enter dry weights in a batch mode and the program will calculate the water content. If not preceded by a letter, the program assumes the actual water content is entered.

WET WEIGHT - in grams, only used when a tare number is entered for the water content.

STRATUM CHANGE - enter this when there is a stratum change before the next sample.

ROCK NOTES - contains the symbol **RO** when rock notes are desired for the sample. The sample number should end in a letter (i.e. 231 A).

ROCK MOD - contains the rock symbol or a modification that prints in the log on the plot program. Only  $SLF\ F\ M\ C\ O\ CS\ SIS\ SS$  modifications are allowed in the log.

GRAD. TARE - tare number for gradation tests. Program will later generate labels for particle size test forms.

CONSISTENCY - see Appendix B for allowable codes.

COLOR - see Appendix B for allowable codes.

MODIFICATION SYMBOLS - see Appendix B for allowable codes. There are some restrictions as to which modifications may be used with certain soils or other modifications:

F M C VD D LO - only used with sand soils (SW or SP) CR SL - only used with clay soils (CL or CH) TR must be followed by G two letter modifications should be left justified one letter modifications should be centered

BLOWS PER FOOT - this is a character field that should only contain numbers and/or the symbol '+'. If '100+' is entered '101' is sent to the plot program.

D10 SIZE - may either be n.nnn or .nnnn significant digits

UCT, ATTERBERG LIMITS, TESTS WATER CONTENT, SECOND UCT, and TESTS ASSIGNED are self-explanatory.

The COMMANDS menu for the sample data input screen may be accessed at any time by pressing the <PageDown> key. The menu appears at the bottom of the screen.

Project: Boring Nu						Sample Scratc			
SAMPI FROM 5.8	TO	CONTENT	WEIGHT	STRATUM CHANGE 8.0		ROC NOTES		GRAD. TARE	
	CONS T <b>E</b> M	iCY	COLO BR	R		FICATIO	N		
BLOWS PER FOOT	UC <b>T</b> 0	ATTEI LL 25		D10 SIZE 0.0000	CONT	WATER ENT O	SECONI UCT 0	TESTS ASSIGNED	
COMMENTS:									
COMMANDS  Redo Update Delete Next Menu Codes  Enter action selection > <									

To execute any of the commands, press the letter key corresponding to the first letter of the command.

#### SAMPLE SCREEN COMMAND MENU

R - Redo	Repaints Sample Screen and allows user to continue editing record.
U - Update	Adds sample to database if new sample or updates information in database record if old sample.
D - Delete	Deletes sample from database.
N - Next	Displays next sample in the database.
M - Menu	Returns program to main menu.
C - Codes	Displays available codes on the screen for user and returns to proper place on Sample Screen.  C - Color codes.  M - Modification codes.  S - Soil codes.  R - Rock codes.  T - consisTency codes.

NOTE: You MUST UPDATE to make any addition and/or change to the database!

You may not modify the sample number. To correct this simply delete the incorrect sample number and add a correct one and its associated data.

Project: Boring Nu							COLOR	1
SAMPL FROM 5.8 BLOWS PER FOOT	<del></del>	WATER CONTENT 19 IS- CY	O.O COLO	8.0	S M S TES C	T Y R BK GR LGR DGR BR LBR DBR GN BL WH MOT BRG GYB GNG	Tan Yellow Red Black Gray Light Gray Dark Gray Brown Light Brown Dark Brown Green Blue White Mottled Brownish-gray Grayish-brown Greenish-gray	STS GNED
	Со			CODES ions Soil ion select	П	GYG BLG RD	Grayish-Green Blue-Green Reddish	

Press any key: >

The above is an example of displaying allowable color codes while editing a sample. This screen was reached by the following keystrokes: <PageDown> C C

Control will be returned to the first COLOR blank on the Sample Screen when the user presses a key.

#### OPTION 4 - PRINT BORING/SAMPLE

This option prints the boring log. The printout includes the information associated with the boring record and the detailed information associated with each sample. It is recommended that the user print the boring log after entering sample data for each boring. See Appendix C for and example of the boring log printout.

#### OPTION 5 - LIST EXISTING BORINGS TO SCREEN

This option displays on the screen the boring ID's of all borings entered into the database.

#### OPTION 6 - DISPLAY BORING/SAMPLES

This option displays on the screen the same information printed in the boring log report. The first screen contains the information associated with the boring record. The second screen contains the sample information through the modifications. Optionally, the user may view the remaining sample information or move on to the rest of the samples.

#### LABORATORY LOG

PROJECT NAME: TOWN CREEK BORING NO. TC-1-87U LOCATION 6' FROM TOP BK

FIELD BOOK NOS. 7228 DATE TAKEN 16 Jun 87

G. S. ELEVATION 313.7 TERTIARY DEPTH
WATER TABLE DATE: 16 Jun 87 WATER TABLE DEPTH: 25.0
METHOD OF DRILLING: Rotary Mud LOCAL N-S COORD.: 0.00
GENERAL SAMPLES: 2.5" Drive Tube LOCAL E-W COORD.: 0.00
UNDISTURBED SAMPLES: Vacuum Type Shelby Tube
CLASSIFIER: JDC RECORDER: BB CHECKER: BB
DATE ANALYZED: 15 Jun 87 DATE CHECKED: 26 Jun 87

Press any key to continue...

The first screen contains general information about a boring.

PROJECT NAME: TOWN CREEK BORING NO. TC-1-870

TESTS ASGN	SAMPLE NO.	SAMP FROM	LE TO	WATER	STRATUM CHANGE	SYM	CONSIS- TENCY	COLOR	MODIFICATION SYMBOLS
<del></del>	NSN	0.0	1.0	<del></del>	1.0	SP	<del></del>	BR	G
S	1A	5.0	5.8						
	1	5.8	6.0	19	8.0	ML		BR	S
s	2A	10.0	10.8						
	2	10.8	11.0	41	13.0	ML	CS	BR	
	3	15.0	16.0		18.0	SM		GR	
	4	20.0	21.0	18	23.0	$\mathtt{CL}$		LGR	ISS
	5	25.0	26.0			SP		BR	F

Press C to see the rest of the data on these borings or any other key to go on

The second screen displays partial data for samples. Optionally the user may continue < C> viewing information for the above samples or press any other key to move on to the remaining samples for this boring.

PROJECT NAME: TOWN CREEK BORING NO. TC-1-870

TESTS ASGN	SAMPLE NO.	SAMP FROM	LE TO	BLOWS PER FOOT	UCT		RBERG MIT PL	D10 SIZE	TEST WATER CONTENT	SECOND UCT
					•				<del></del>	
	NSN	0.0	1.0							
S	1 A	5.0	5.8							
	1	5.8	6.0			25	18			
S	2 <b>A</b>	10.0	10.8							
	2	10.8	11.0			40	31			
	5	15.0	16.0							
	4	20.0	21.0							
	5	25.0	26.0							

Press P to go back to previous screen or any other key to go on

Remaining information about the samples shown in the prior screen.

107E: The "3" appearing in the first column indicates that the sample has been "Scratched".

Modifications to be placed in the log or ROCK symbols appear between SYM and CONSISTENCY.

#### OPTION 7 - CREATE NEW BORING DATABASE

Use this option to move some of the borings to another database. This may be done by individual boring ID's or by Project. First you must enter a filename for the new database:

Create a new database file.

New filenames maximum length is seven characters.

Enter the new name and press RETURN

New Filename:

If the filename already exists:

If you choose to Overwrite - all existing records in that file will be ERASED!

If you choose to Append - records will be added to those in the existing file.

Boring Duplicates

- 1. Project
- Location (not implemented)
- 3. Boring I.D.
- 4. Return to Main Menu

Choose an Option -->

Project - all borings with the same project name will be copied to the new database. This is only helpful if you have used more than one project name in your current database.

Boring I.D. - copies one boring at a time until the user enters a blank boring ID to the new database.

#### OPTION 8 - GENERATE PLOT FILES

This option allows the user to create a standard ASCII file in the format expected by the boring plot routine. Borings may be selected by entering a range or by specifying up to 11 specific borings. Placement of logs on the plot is calculated according to the default placement tables.

First enter a filename for the ASCII file with no extension. The program will automatically append ".txt" to the name you enter. If the file already exists, the user may overwrite it (erasing previous data) or enter a different name. Then the user chooses a method of selecting borings:

Do you wish to :

- 1. Enter boring log numbers one at a time (up to 11 logs)
- 2. Enter beginning and ending log numbers
- 3. Return to menu

Enter choice from above

#### Choice 1:

Boring Log No. 1 : TC-1-87U Boring Log No. 2 : TC-2-87U Boring Log No. 3 : TC-3-87U

etc.

Boring log No. n:

Enter blank boring number to finish.

#### Choice 2:

Enter beginning Log number:

Enter ending Log Number :

Remember Log Numbers are sorted in alphabetical order so that TC-10-87U precedes TC-2-87U.

After choosing the logs to be plotted, the program reads through the log sample data and calculates the minimum and maximum ground surface elevation and the lowest depth. As this process proceeds the following screen appears:

working

working

working

\*\*\* Boring not found: TC-3-87U

Do you wish to continue? **y**working

working

The "\*\*\* Boring not found" message only occurs when the user has individually selected borings to be plotted and one of the borings is not in the database. When this occurs, the user may continue and the plot will contain one less boring than the user requested.

logs to be plotted

maximum ground surface elevation: 313.7

minimum ground surface elevation: 300.0

lowest vertical depth: 259.0 press any key to continue ...

When the above information appears on the screen, the user should make a note of the minimums and maximums in order to check for proper placement of individual logs on the plct.

The user is now given the option of modifying or accepting default values for plot options, plate characteristics, titles, and general notes.

#### Plot Option Card Defaults

Only 2 Vertical Staffs per Plate
No horizontal staff
Left and right vertical staffs
Modifications with written descriptions
Vertical Caption: 'ELEVATION IN FEET M.S.L.'
Written descriptions in upper case
Maximum staff is 22", plate is 37" wide
0 lines of notes

Do you wish to change any of the above defaults? The above screen displays the Plot Option Card defaults.

If you wish to modify the Plot Option defaults, your cursor will appear flashing to the left of the options. Press the "x" key to toggle choices on all lines except the number of note lines. For that option use a "+" to increase the number of note lines and a "-" to decrease them.

#### Plot Option Card Defaults

Only 2 Vertical Staffs per Plate
No horizontal staff
Left and right vertical staffs
Modifications with written descriptions
Vertical Caption: 'ELEVATION IN FEET M.S.L.'
Written descriptions in upper case
Maximum staff is 22", plate is 37" wide
0 lines of notes

Use arrow keys to position and "x" to modify Press <PgDn> when finished

The next screen displays the calculated Plate Characteristic Card values. Use the arrow keys to move the cursor and make any necessary modifications. When satisfied with the values, press the PageDown key.

# Plate Characteristic Card Maximum distance of horizontal staff in feet 340.0 Upper vertical staff elevation 320. Lower Vertical staff elevation 300. Vertical scale 10.0 Horizontal scale 10.0 Size of plate factor 1.000 Number of boring logs to plot 1 Starting horizontal staff distance 0.00 Forcent to increase letter size in scaled plot 0.

Use arrow keys to position, press <PgDn> when finished.

The user will enter the titles for the plate and then the appropriate number of notes to appear beside the title block.

Title lines 1 - 3 may have up to 38 characters

Title line 4 has up to 19 characters

Title lines 5 - 6 may have up to 45 characters

Notes may have up to 45 characters per line.

The user may use the up and down arrows to make corrections in the titles until he presses the PageDown key. Titles should be left justified within the fields.

After entering the title and note lines, the program begins to generate the individual boring log plot data. For each boring to be plotted the following information will appear on the screen:

Boring Number: TC-1-87U Project: TOWN CREEK

Location: 6' FROM TOP BK GSE: 313.7

Tertiary: 223.4

Local N/S Coordinate: 0.00 Local E/W Coordinate: 0.00

Enter Distance from left vertical staff 60.00

Enter ground surface elevation 313.7

The user may accept the distance from the left vertical staff and the ground surface elevation by pressing return; or may modify one or both. A bell will sound when the next boring is displayed on the screen.

#### OPTION 9 - MISCELLANEOUS

#### 1 - Gradations Labels

This option allows the user to print labels to be placed at the top of particle size forms. An example follows:

PROJECT: TOWN CREEK

Boring No. Sample No.

TC-2-87U

Depth: 1.5 TO 3.0 Tare: B35

Total Weight of Sample \_\_\_\_\_ Grams

#### 2 - Water Content Forms

In this module, the user enters the dry weights for the tare numbers entered when soil samples came into the lab. The program computes the water content and places that number in place of the tare number in the database. At the same time a printout detailing calculations is generated. See Appendix D for an example of the printout.

#### 3 - Ascii dump of databases

Dumps all information in database into ascii files delimited by quotes.

NOTE If you get to OPTION 9 by mistake, choose Number 1 (Gradations Labels) and enter a blank boring number to return to the Main Menu.

#### OPTION 0 - VALIDATE DATABASE

This module checks for errors in the database. Lab personnel should run this routine when finished entering data for a project before giving the data to the section that will plot it.

Checks are made for improper codes, missing stratum changes, and other missing data. If the user indicates that tertiary and water table data are available, warnings are issued if data are missing. See Appendix E for sample printout.

#### BACKING UP THE DATABASE

At the end of every day that the program has been used, make a backup of the databases used.

Enter "Q" at the main menu.

Exit dBase by typing QUIT

Place a formatted floppy diskette in drive B

Enter the copy command:

COPY filename\*.\* B:

Now a current copy of that database is saved on the floppy. Label the floppy with the database name and the date. After you have made 3 backups of the database on different days, you may copy onto the oldest of these diskettes.

#### FORMATTING NEW DISKETTES

Change the default drive to  $\Lambda$ :

A:

#### FORMAT B:

The program will prompt you to place a new floppy in drive B: and press ENTER to continue. When it is finished, the user has an option to format another.

Struct	ure for data	base: A:BOR	STRB.dbf	
	of data rec			
	f last updat			
	Field Name			Dec
	BOR_NUM			
2	TERT DEPTH	Numeric	6	1
3	LOCN_1	Character	32	
4	LOCN_2	Character	22	
5	LOCN_3 LOC_NS	Character	22	
6	LOC NS	Numeric	I ()	• • • •
7	LOC _EW	Numeric	10	2
8	DATE_TAKEN WTAB_DATE	Date	8	
9	WTAB_DATE	Date	8	
10	WTAB_DEPTH	Numeric	6	1
11	METH_DRILL	Character	3	
12	GEN_SAMPLE	Character	3	
13	UND_SAMPLE	Character	3	
14	PROJECT	Character	30	
15	CLASSIFIER	Character	3	
16	RECORDER	Character	.3	
17	CHECKER	Character		
18	DATE_ANAL	Date	8	
	DATE_CHECK		8	
20	FBOOK_NOS	Character	ŲŌ	
	$GS\_\Xi LEV$			ì
22	REMARK	Character	<b>6</b> C	
** Tot	al **		296	

Struct	ure for data	base: C:BOR	STRS.dbf	
	of data rec		0	
Date o	f last updat	e : 06/25	/90	
	Field Name			Dec
	SAMPLE_NO			
	TST_ASGN	Character		
3	SFROM	Numeric	5	1
4	STO	Numeric	5	1
ច៍	WATER_CONT	Character	3 5 5	
6	WET_WGT	Numeric	5	1
7	STRAT_CHG	Numeric	5	1
8		Character	2	
	ROCK1	Character	2 2 3	
	ROCK2	Character	3	
11		Character	-4	
	CONSIS	Character		
1 3		Character		
14	COLOR2	Character		
	COLOR3			
16		Character	3	
17		Character		
	MSYM3	Character		
	MSYM4	Character	5	
20	BLOWS FT	Character	4	
		Numeric	1	
22	ATLIM_LL	Numeric	3	
23		Numeric	3	
2.4	D10_SIZE	Numeric	3 7	4
25	TWAT_CONT	Numeric	3	
	SECOND_UCT		4	
	REMARKS		1	
28		Logical	1	
非本 Tot.	al **		125	

Structure for database: C:BORSTRR.dbf Number of data records: 0 Date of last update : 06/25/90 Field Field Name Type Width 1 SAMPLE_NO Character 36 2 REMARK Character 60 ** Total ** 97	Dec
Structure for database: C:abrev.dbf Number of data records: 14 Date of last update : 11/18/87 Field Field Name Type Width 1 ABR Character 3 2 NAME Character 25 ** Total ** 29	Dec
Structure for database: C:plot.dbf Number of data records: 17 Date of last update : 10/25/90 Field Field Name Type Width 1 REC80 Character &0 ** Total **	Dec
Structure for database: C:plotbors.dbf Number of data records: 1 Date of last update : 10/25/90 Field Field Name Type Width 1 BNAME Character 26 ** Total ** 27	Dec

	DRILLING METHODS
AUG COR D25 DEN FT4 FT6 FT8 HDA HVO RM RNM SSS VST	2.5" Drive Tube Denison Sampler Fishtail 4" Fishtail 6" Fishtail 8" Hand Auger
	•

	ROCK CLASSIFICATIONS
GRA	Grayacke
CLA	Indurated Clay or Claystone
CEM	Cemented Shale
COA	Coal
LIM	Limestone
DOL	Dolomite
MAR	Marble
DIO	Diorite
BAS	Basalt (Trap)
TUF	Tuff or Tuff Breccia
GNE	Gneiss
SCH	Schist
n -	Quartzite
SOA	Soapstone and Serpentine
11	Gabbro
	Rhyolite
11	Andesite
SLA	Slate
	Granite
SIL	Siltstone
COM	
CHA	Chalk or Marl
17	Sandstone
	Conglomerate
AGG	2 2
NSP	Prevents Plotting of Rock Symbols

	COLOR
T Y R BK GR LGR DGR BR CH BR DBR CH MOT BRG	Tan Yellow Red Black Gray Light Gray Dark Gray Brown Light Brown Dark Brown Green Blue White Mottled Brownish-gray
BRG GYB	Brownish-gray Grayish-brown
GNG GYG BLG RD	Greenish-gray Grayish-Green Blue-Green Reddish

## CONSISTENCY

VSO Very Soft SO Soft M Medium ST Stiff

VST Very Stiff

H Hard

#### SOIL CLASSIFICATIONS

- GW Gravel, Well Graded, Gravel-Sand Mixtures, Little or no Fines
- GP Gravel, Poorly Graded, Gravel-Sand Mixtures, Little or no Fines
- GM Silty Gravel, Gravel-Sand-Silt
- GC Clayey Gravel, Gravel-Sand-Clay
- SW Sand, Well-Graded, Gravelly Sands
- SP Sand, Poorly-Graded Gravelly Sand
- SM Silty Sand, Sand-Silt Mixtures
- SC Clayey Sand, Sand-Clay Mixtures
- NS No Sample
- ML Silt and Very Fine Sand, or Clayey Fine Sand or Silt with Slight plasticity
- CL Lean, Sandy, Silty Clay of Medium plasticity
- OL Organic Silts and Silty Clays of Low plasticity
- MH Silt, Fine Sandy or Silty Soil with High plasticity
- CH Fat, Inorganic Clay of High plasticity
- OH Organic Clays, Silts of Medium to High Plasticity
- PT Peat, other Highly Organic Soil

Company of the Compan

- WD Wood
- SI Shells
- DB Debris

	MODIFICATIONS
TR	Traces
F	Fine
M	Medium
C	Coarse
CC	Concretions
RT	Rootlets
LG	Lignite Fragments
SH	Shale Fragments
SDS	
SLF	
0	Organic Matter
CS SIS	Clay Strata or Lenses
S	
G G	Sandy Gravelly
В	Boulders
SL	Slickensides
WD	Wood
ox	Oxidized
SSI	
ISS	
PGM	Poorly graded Silty
	Fine Gravel
WGM	· - · · <b>1</b>
}	Fine Gravel
PGC	1 1 - 1
	Fine Gravel
WGC	
DCM	Fine Gravel
PSM	
PSC	Fine Sand
150	Poorly Graded Clayey Fine Sand
WSM	
	Fine Sand
WSC	
	Fine Sand
LML	i
VEG	
SS	Sand Strata
SI	Shells
CR	Crumbly
W/	With
LO	Loose
VD	Very Dense
D	Dense

LABORATORY LOG Page 1 Project name: TOWN CRIEK Field Book No. 7228 Date Taken 16 Jun 87 Boring no. TC-1-870 6' FROM TOP BE Location

G. S. Elevation 313.7 Tertiary Depth

Water table date: 16 Jun 87 Water table depth: 25.0

LOCAL M-S COORD. : 0.00 Method of drilling: Rotary Med General samples: 2.5° Drive Tube
Undisturbed samples: Vacuum Type Shelby Tube LOCAL E-W COORD. : 0.00

Classifier: JDC Recorder: BB Checker: BB Date analyzed: 15 Jun 87 Date checked: 26 Jun 87

TESTS	SAMPLE NO.	SAN			STRATUR		ROCE	COUS IS TRUCT	COLOR	BODIFICATION STRBOLS	BLOWS PER FOOT	UCT	LI	RBERG MIT PL	D10 SIZE	TEST WATER CONTENT	SECOND
	HSN	0.0	1.0		1.0	SP			BR	G							
S	14	5.0	5.8														
	1	5.8	6.0	23	8.0	ĦĹ		9	BR	S			25	18			
S	21	10.0	10.8														
	2	10.8	11.0	20	13.0	ĦĹ	CS		BR				40	31			
	3	15.0	16.0	19	18.0	SM			GR								
	4	20.0	21.0	11	23.0	CL			LGR	ISS							
	5	25.0	26.0	21		SP			88	ŗ					0. 1820		
	6	30.0	31.0	18		SP			LGR	ŗ					0. 1940		
	7	35.0	36.0	28	38.0	SP			LGB	t					0.1770		
	8	40.0	41.0		41.0	SM			LBR	PSM					0. 1020		

Boring complete at 41.0

## WATER CONTENT - GENERAL

Date: 07/28/87

Project: TOWN CREEK

Boring No. TC-1-87U

Sample No. Tare No.	1 M19	2 M20	3 M21	4 M22	5 M23	6 M30
Tare plus wet soil	123.0	230.0	187.5	200.0	120.0	222.2
Tare plus dry soil	100.0	192.0	157.0	180.0	99.0	189.0
Water (grams)	23.0	38.0	30.5	20.0	21.0	33.2
Water content (%)	23	20	19	11	21	18

Sampl Tare	le No.	•		7 M31
Tare	plus	wet	soil	190.0
Tare	plus	dry	soil	148.0
Water	<del>.</del>	(gı	cams)	42.0
Water	cont	ent	(%)	28

	Project:	TOWN CREEK	07/29/87
WARNING TC-1-87U WARNING TC-1-87U WARNING TC-1-87U WARNING TC-10-87U ***ERROR*** TC-10-87U ***ERROR*** TC-10-87U ***ERROR*** TC-10-87U WARNING TC-13-87U ***ERROR*** TC-2-87U WARNING TC-22-87U WARNING TC-22-87U WARNING TC-22-87U WARNING TC-22-87U WARNING TC-22-87U **** ERROR ***TC-23-87U WARNING TC-23-87U WARNING TC-23-87U WARNING TC-23-87U WARNING TC-3-87U **** ERROR *** TC-3-87U **** ERROR *** TC-3-87U **** ERROR *** TC-3-87U ***ERROR*** TC-3-87U ***ERROR*** TC-3-87U ***ERROR*** TC-4-87U ***ERROR*** TC-4-87U ***ERROR*** TC-4-87U ***ERROR*** TC-5-87 ***ERROR*** TC-5-87 ***ERROR*** TC-5-87 ***ERROR*** TC-6-87U ***ERROR*** TC-6-87U ***ERROR*** TC-6-87U ***ERROR*** TC-6-87U ***ERROR*** TC-6-87U WARNING TC-7-87U WARNING TC-8-87U WARNING TC-9-87U **** ERROR*** TC-6-87U WARNING TC-8-87U WARNING TC-8-87U WARNING TC-8-87U WARNING TC-9-87U WARNING TC-9-87U WARNING TC-9-87U WARNING TC-9-87U WARNING TC-8-87U	5 6 7 2 5 6 1 NSN NSN 4 NSN 2 NSN NSN 2 NSN 8 8	Water content and D-10 size on sam Sandy modification on non-sand sam Bad Color code: LR Bad Color code: LR Missing Location. Missing Stratum change Missing or zero G.S. Elev Missing field book numbers. Missing Location. No samples for this boring. Missing or zero G.S. Elev Missing field book numbers. Missing Date Taken. Missing Date Taken. Missing Symbol Code. Missing Symbol Code. Missing stratum change Missing stratum change Missing Symbol Code. Missing Stratum change Bad Modification Code: TRG Missing Stratum change Bad Color code: LR Bad Color code: LR Missing stratum change Bad Modification Code: G. "TR" mod not followed by "G" Bad Color code: LR Missing Location. Tertiary depth > last stratum change Missing Location. Missing Location. Missing Date Taken. Missing Date Taken. Missing Date Taken. Missing Location.	e sample e sample e sample ple
**** ERROR****TCA-1-87U		No samples for this boring.	

#### TECHNICAL DOCUMENTATION

F-1


The Boring Log Database System operates in a dBase III Plus environment. It consists of 23 program modules, three support database files and three database files per project. Each time the user creates a new database by entering a seven character filename, the system actually generates three files:

### Support files include:

ABREV.DBF - abbreviations for drilling methods indexed by abbreviation PLOT.DBF - a temporary file used to generate plot data PLOTBORS.DBF - a temporary file used to save boring ID's to plot

Database structures for the above files are listed in Appendix A.

#### STRUCTURE DIAGRAM FOR PROGRAM MODULES



#### TECHNICAL DOCUMENTATION

F-2

#### BORING. PRG

The main program is **BORING.PRG**. It solicits a database filename, creates it if it doesn't exist, opens the databases, and drives the main menu.

For each database name (up to 7 characters long) that the user enters, the system creates 3 database files and 4 index files by appending a character and the proper extension to the name.

Workarea 1 - general boring information - file B.dbf indexed by boring ID

Workarea 2 - sample information - file**S**.dbf indexed by boring ID + sample no. + depth or by boring ID + depth + sample no.

Workarea 3 - remarks associated with samples - fileR.dbf indexed by boring ID + sample no. + depth

These workarea assignments remain constant throughout the system, except when creating a copy of part of the database.

When the database is opened, the system checks the first record for the project name to use for the default. If there is no project name, the user must enter one. The system then checks the master project file for the project name. If it is not there, the system solicits site coordinates and places the new project and current date in the database. Each time the project is accessed, the current date is placed in the last date used field.

After processing project and file information, the main program loops around the main menu until the user enters a "Q" to quit.

#### BORBADD, PRG

This module solicits a boring ID to add to the database. It checks workarea 1 to see if the ID already exists and will not allow duplicates. Then it presents a full-screen data entry screen to get information about the boring and adds the record to the database.

#### BORBUPD, PRG

The module allows the user to modify or delete a boring record in the database. The boring must exist. The user may not change the boring number. When the boring is deleted all samples are also deleted.

#### TECHNICAL DOCUMENTATION

F-3

#### BORSADD.PRG

This module allows the user to view or modify and existing sample, or add a new sample to the database.

The sample number is entered as three variables: SN (3 characters), SU (1 character) and SR (1 character). SN is the number part and should be all numeric or "NSN" for no sample number. The program right justifies the number in SN. SU is used by lab usually to indicate an undisturbed sample. SR should be lettered sequentially for rock notes. If SR is not blank the program assumes a sample with a rock note is being entered.

The sample number is appended to the boring ID to create the variable SCHECK for the search condition to see if it is in the database. If it is not found, variables are set to blanks; otherwise, they are set to current values in the database.

LOOP2 is the full-screen data entry section. Control goes to various fields depending on whether the user has selected to view valid codes from the Sample Screen Menu. If the user requested to view colors, data entry will begin with the first color code.

LOOP1 is executed until the user selects "M" from the Sample Screen Menu to return to the Main Menu.

#### ADDMENU. PRG

This module displays the Sample Screen Menu and executes the selected function. It is called from BORSADD.PRG each time the read is executed from the full-screen get. The conditional REPLACE's were used to speed execution time. If the user wishes to view allowable codes the program calls one of the window programs:

COL\_WIN.PRG - colors
ROC\_WIN.PRG - rocks
SOIL\_WIN.PRG - soils
CONS\_WIN.PRG - consistency
MOD\_WIN.PRC - modifications

#### BORPRINT . PRG

This module prints the Laboratory Log, a 132 character per line printout of a boring's general information and sample data. The sample index is set to fileD.ndx where depth is more significant than sample number. Device is set to print.

#### TECHNICAL DOCUMENTATION

F-4

#### SHOWBOR. PRG

This module lists on the screen all boring numbers in the boring database. This does not ensure that each boring has a complete set of sample data.

#### BORSCR.PRG

This module does the same as BORPRINT but puts the information on the screen. The sample data is shown half at a time along with depth information. The user may toggle between the two screens.

#### DETOUR.PRG

This module will create another database file adding chosen borings' records to it. If the database already exists, the user may append or overwrite it. Workareas 4, 5, and 6 are used for the new database files corresponding to current workareas 1, 2, and 3. Because of limitations on the number of files opened and the necessity of using closed files for the "APPEND FROM" statements, the current database files are closed in this routine. They are reopened before returning to the main menu. The user may choose to select individual borings or all with the same project code to add to the new database.

#### BORPLOT.PRG

This module generates an ascii text file in the format expected by the plot program on the Harris minicomputer. A temporary database file, PLOT.dbf in Workarea 4 is used containing 80 character single field records. All data is placed in this file during execution. At the end of the routine a "COPY ... SDF" command copies it to the file selected by the user.

The program allows the user to enter a beginning and ending boring ID or enter up to 11 boring ID's to be plotted. If boring ID's are entered one at a time, they are stored in a temporary database file, PLOTBORS.dbf in Workarea 5 and are placed in the plot file in the ordered entered. After the user selects the desired borings, the program reads through all samples to be plotted and calculates the maximum ground surface elevation and the minimum depth to be plotted. These numbers are used in deciding the default scale in the Plate Characteristic module. This program calls three support modules:

#### TECHNICAL DOCUMENTATION

F-5

- PLOTIT.PRG A routine to build the Plot Option "card" for the plot program. Default values are displayed on the screen. The user moves the cursor with the arrow keys or presses the "x" key to change the default. The PageDown key exits the routine. The number of notes is changed by using the "+" or "-" key. The routine is driven by a case statement based on which key is pressed; and by another case statement based on which row on the screen the cursor in on.
- PLATCHAR.PRG A routine to build the Plate Chara maristic "card". Default values are displayed and the user may change them. The scale depends on the distance between the highest and lowest points to be plotted on the plate. The horizontal placement depends on the number of borings to be plotted. At this time the horizontal increment is also chosen based on the table available with the plot program documentation.
- PLOTITLE.PRG A routine that places title and notes records in the plot file.

For each boring several header "cards" are put in the plot file:

- 1 ground surface elevation and horizontal placement
- 2 boring ID and tertiary (if any)
- 3 first location field from database
- 4 second location field from database
- 5 field book numbers
- 6 date taken and water table depth (if any)

After these records are written to the plot file, all samples (except those that have been scratched) are written to the file. Some editing of data is done at this time such as:

centering single character modifications

left justifying two character modifications

checking precision of d10\_size - can only use 5 places (n.nnn or .nnnn)

checking for rock notes in order not to send more depth info

At the end of each boring's sample records, a record consisting of "999.9" is placed in the plot file.

See Appendix G for format of plot data file.

#### TECHNICAL DOCUMENTATION

F-6

#### GRADLAB, PRG

This routine produces labels for the particle size test forms. The user enters a boring ID and the program reads through the samples for that boring and makes labels for those that have a tare number in the GRAD TARE field.

#### WATERCON. PRG

This module reads through the samples for a particular boring ID; and if the WATER\_CONT field begins with a letter, requests a dry weight from the user and calculates the water content percent. The formula for the water content is: (wet wgt - dry wgt) / wet wgt.

Values for sample number, wet weight, dry weight, tare number, water weight and percent water are stored in memory variables for up to 6 samples. When 6 have been calculated or the end of the boring is reached, they are printed across the page.

#### **BORTRANS**

This routine produces ascii files containing all information in the databases in comma separated fields.

#### BOREDIT

This routine performs most of the same data checks as BLOG9 does on the Harris to determine bad data for the plot program. The program checks for valid codes and combinations of codes. It also checks for missing stratum changes and incorrect depths. The conditional statements and error messages are pretty much self-explanatory.

#### FIXDATE

A routine to convert a string date in the format nn MON yy (23  $_{
m JUI}$ , 87) to a dBase type date field. It is used by several of the modules.

## PLOT DATA FILE FORMAT

G-1

PLOT OPTION CARD  cols 1 - 5 vertical staff option  cols 6 - 10 horizontal staff option  cols 11 - 15 horizontal & vertical staff option  cols 16 - 20 log modification option  cols 21 - 25 vertical staff caption option  cols 26 - 30 description caption option  cols 31 - 35 staff length and plate width option  cols 36 - 40 increase or decrease 4 notes by this number  cols 41 - 45 "1"
PLATE CHARACTERISTIC CARD
cols 1 - 10 maximum distance of horizontal staff cols 11 - 15 lower vertical staff elevation cols 16 - 20 upper vertical staff elevation cols 21 - 25 vertical scale cols 26 - 30 horizontal scale cols 31 - 35 size of plate factor cols 36 - 40 total number of logs cols 41 - 50 starting horizontal staff distance cols 51 - 55 percent to increase letter size cols 56 - 60 "4" cols 61 - 65 "7"
PLATE TITLE CARDS (6)  cards 1 - 3 maximum 38 characters  card 4 maximum 19 characters  cards 5 - 6 maximum 45 characters
GENERAL NOTES CARDS (4 +/- number from Plot Option card) maximum 45 characters
REPEAT GROUP FOR EACH LOG:
BORING LOG PLACEMENT CARD  cols 1 - 10 distance from vertical staff  cols 11 - 20 ground surface elevation
LOG IDENTIFICATION CARDS (5)  1 - cols 1 - 26 boring ID  cols 35 - 39 tertiary depth  2 - cols 1 - 35 location description  3 - cols 1 - 22 location description  4 - cols 1 - 22 field book number  5 - cols 1 - 22 date taken  cols 23 - 29 water table date  cols 31 - 35 water table depth

#### PLOT DATA FILE FORMAT

G-2

```
SAMPLE DATA CARDS (varies)
     cols 1 - 5
                    from depth
          6 - 10
     cols
                    to depth
     cols 11 - 13
                    water content
     cols 14 - 18
                    stratum change
     cols 19 - 20
                    soil symbol
     cols 21 - 22
                    rock note indicator
     cols 23 - 25
                    log modification or rock code
     cols 26 - 28
                    consistency
     cols 29 - 31
                    color
     cols 32 - 34
                    color
    cols 35 - 37
                    color
    cols 38 - 40
                    modification
    cols 41 - 43
                    modification
    cols 44 - 46
                    modification
    cols 47 - 51
                    modification
    cols 52 - 55
                    blows per foot
    cols 56 - 59
                    uct
    cols 60 - 62
                    blank
    cols 63 - 65
                    Atterberg 11
    cols 66 - 68
                    Atterberg pl
    cols 69 - 73
                    d10 size
    cols 74 - 76
                    test water content
    cols 77 - 80
                    second uct
```

END OF LOG INDICATOR (999.9)

## + UNIFIED SOIL CLASSIFICATION

MAJOR DIV	VISION		LETTER		TYPICAL NAMES												
<del></del>		CLEAN		BO.													
v 💺 💃	2 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	GRAVEL	G W		GRAVEL, Well Graded, gravel-sand mixtures, little or no fine												
SOILS In Inger	Fraction Fraction Fraction	(Little or No Fines)	GP		GRAVEL, Poorly Graded, gravel-sand mixtures, little or no fines												
- 2	More the coorse fr larger th	GRAVEL WITH FINES	G M	X	SILTY GRAVEL, gravel-sand-silt mixtures												
GRAINED of meteri	102	Amount of Fines)	GC		CLAYEY GRAVEL, gravel -sand - clay mixtures												
ARSE - GRAII then helf of m Ne. 200 steve ANDS	5 2 4	CLEAN SAND	s w	$\Xi$	SAND, Well - Graded, gravelly sands												
SE - 200 200 105	than half e.fraction er than M	(Little or Na Fines)	SP		SAND, Poorly-Graded, gravelly sands												
COARSE -		SANDS WITH FINES (Approcraphs	S M	H	SILTY SAND, sand - silt mixtures												
00 8 8	1 3 E	Amount of Fines	s c		CLAYEY SAND, sand-clay mixtures												
SOILS 200	SILTS AND		ML		SILT & very fine sand, silty or clayey fine sand or clayey sill												
D SOIL he mater No. 200		(Liquid Limit									CLAYS				CL		LEAN CLAY; Sandy Clay; Silty Clay; of low to medium pla
GRAINED on helf the er then R		< 501	OL		ORGANIC SILTS and organic silty clays of low plasticity												
		SILTS AND	мн		SILT, fine sandy or silty soil with high plasticity												
1 4 5 5	S S S S S S S S S S S S S S S S S S S		СН	1//	FAT CLAY, inorganic clay of high plasticity												
F B S			ОН		ORGANIC CLAYS of medium to high plasticity, organic sil												
HIGHLY (	ORGANIC	SOILS	Pt		PEAT, and other highly organic soil												
	WOOD		Wd		WOOD												
NO	SAMPLE	~															
<del></del>				$\dashv$													
L																	

NOTE: Soils possessing characteristics of two groups are designated by combinations of groups a comma will be used between modification symbols. Example. So,Gr,w/SS,SIS,(CH)

## DESCRIPTIVE SYMBOLS

COLOR			CONSISTENCY	
COLOR	SYMBOL		FOR COHESIVE SOILS	· · · · · · · · · · · · · · · · · · ·
TAN	T	CONSISTENCY	COHESION IN LBS / SQ FT FROM	
YELLOW	٧	0011313121101	UNCONFINED COMPRESSION TEST	7 31
RED	R	VERY SOFT	< 250	v S o
BLACK	BK	SOFT	250 - 500	So
GRAY	Gr	MEDIUM	500 - 1000	M
LIGHT GRAY	IGr	STIFF	1000 - 2000	SI
DARK GRAY	d G r	VERY STIFF	2000 - 4000	v S1
BROWN	8-	HARD	- 4000	н
LIGHT BROWN	I Br			
DARK BROWN	d Br	× 60		
BROWNISH - GRAY	br Gr	NO		X-
GRATISH BROWN	gy Br	1 1	CH	
GREENISH - GRAY	gn Gr	<u></u>		- <del>!</del>
GRAYISH - GREEN	gy Gn	<u> </u>	S. J.	
GREEN	Gn	ST		- 1 1
BLUE	81	450	CLOH	
BLUE - GREEN	B1Gn	a	CL-MLY OI MH	
WHITE	Wh	<u>-</u>	OL	- 1
MOTTLED	Mot	ه ا	ML	;
REDDISH	10	0	20 40 60 80	100
			L L - LIQUID LIMIT PLASTICITY CHART	
		_	classification of fine - grained so	

## + UNIFIED SOIL CLASSIFICATION

TYPE	LETTER SYMBOL		TYPICAL NAMES
CLEAN GRAVEL	G W	1	GRAVEL,Well Graded, gravel-sand mixtures, little or no fines
(Little or No Fines)	GP		GRAVEL, Poorly Graded, gravel-sand mixtures, little or no fines
GRAVEL WITH FINES	& M	K	SILTY GRAVEL, gravel-sand-silt mixtures
Amount of Fines):	GC		CLAYEY GRAVEL, gravel -sand - clay mixtures
SANO	S W	:	SAND, Well-Graded, gravelly sands
No Fines	SP	$\vdots$	SAND, Poorly-Graded, gravelly sands
SANDS WITH FINES	SM		SILTY SAND, sand - sllt mixtures
Amount of Fines	s c		CLAYEY SAND, sand-clay mixtures
SILTS AND	ML	Ш	SILT & very fine sand, silty or clayey fine sand or clayey silt with slight plasticity
CLAYS	CL		LEAN CLAY; Sandy Clay; Silty Clay; of low to medium plasticity
< 50)	OL		ORGANIC SILTS and organic silty clays of low plasticity
SILTS AND	мн		SILT, fine sandy or silty soil with high plasticity
CLAYS (Liquid Limit	СН		FAT CLAY, Inorganic clay of high plasticity
> 50)	ОН		ORGANIC CLAYS of medium to high plasticity, organic silts
SOILS	Pt		PEAT, and other highly organic soil
	Wd		WOOD

ossessing characteristics of two groups are designated by combinations of group symbols a will be used between modification symbols. Example. So, Gr, w/SS, SIS, (CH)

## DESCRIPTIVE SYMBOLS

LOR CONSISTENCY					MODIFICATION	S	MODIFICATIO	NS
	SYMBOL	FOR COHESIVE SOILS			MODIFICATION	SYMBOL	MODIFIC ATION	SYMBOL
	Ť		COMESION IN LBS/SQ FT FROM		Troces		Sandy Silt strata	SSIS
	7	CONSISTENCY	UNCONFINED COMPRESSION TEST	SYMBOL	Fine	F	Sitty Sand strata	SISS
	R	VERY SOFT	< 250	v S o	Me dium	M	With	
	BK	SOFT	250 - 500	So	Coarse	С	Dense	_ 0
	G,	MEDIUM	500 - 1000	M	Concretions	cc	Very Dense	<b>▼</b> D
	1Gr	STIFF	1000 - 2000	St	Rootlets	11		
	dGr	VERY STIFF	2000 - 4000	v SI	Lignite fragments	1g		
	Br	HARD	4000	н	Shale fragments	sh		<del></del>
1	18-				Sandstone fragments	sde		
•	d Br	× 60		7	Shell fragments	9.17		<b></b>
MY	br Gr	NOR			Organic matter	0		
OWN	g y Br	2	CH	]	Clay strate or lenses	c s		<u> </u>
RAY	gn Gr	≥40 L			Silt strata or lenses	SIS		
EN	gy Gn	5	3,5		Sand strata or lenses	SS		
	Gn	STIC			Sandy	5		
	B1	d	OL JOH	]	Gravelly	G		
•	BIGn	20	CI-MIN MH		Boulders	8		<b>_</b>
	Wh		CL-ML9 OL		Slickensides	SL		
	Mot		M	1	Wood	Wd		
	7.0	0 L -4		100	Oxidized	0 1		
	<u> </u>	0	20 40 60 80 L L - LIQUID LIMIT	100	Crumbly	Cr		
			PLASTICITY CHART		Loose	Lo		
		E.	classification of fine agrained sails		Ve getation	Veg		_L

NOTES
FIGURES TO LEFT OF BORING UNDER COLUMN "W OR DIO"
Are natural water contents in percent dry weight
When underlined denotes D <sub>10</sub> size in m.m.*
FIGURES TO LEFT OF BORING UNDER COLUMNS "LL" AND "PL"
Are liquid and plastic limits, respectively
SYMBOLS TO LEFT OF BORING
☐ Ground water surface and dare observed
C Denotes location of consolidation test
S Denotes location of consolidated drained direct shear test
P Denotes location of consolidated rundrained triaxial compression test
Denotes location of unconsolidated fundramed friaxial compression test **
Denotes location of sample—subjected to consolidation test and each of the above three types of shear tests—**
FW Denotes free water
FIGURES TO RIGHT OF BORING
Are values of cohesion in lbs /sq ft from unconfined compression tests
In parenthesis are driving resistances. In blows per foot determined with a standard split spoon sampler (1g 1D,200) and a 140 lb driving hammer with a 30 drop
Where underlined with a solid line denotes laboratory permeability in cantimeters per second of undisturbed sample
Where underlined with a dashed line denotes laboratory permeability in centimeters per second of sample remoulded to the estimated natural void ratio

- . The  ${\rm D_{10}}$  size of a soil is the grain diameter in millimeters of which 10 % of the soil
- is finer, and 90% coarser than size  $\mathrm{D}_{10}$

\*\*PResults of these tests are available for inspection in the U.S. Army Engineer District Office, if these symbols appear beside the boring logs on the drawings.

#### GENERAL NOTES

- While the borings are representative of subsurface conditions at their respective locations and for their respective vertical reaches, local variations characteristic of the subsurface materials of the region are anticipated and, if encountered, such variations will not be considered as differing materially within the purview of clause 4 of the contract
- 2 "Ground water elevations shown on the boring logs represent ground water surfaces encountered in such borings on the dates shown. Absence of water surface data on certain borings indicates that no ground water data are available from the boring but does not necessarily mean that ground water will not be encountered at the locations or within the vertical reaches of such borings.
- 3 Consistency of cohesive soils shown on the boring logs is based on driller's log and visual examination and is approximate, except within those vertical reaches of the borings where shear strengths from unconfined compression tests are shown.
- L The detailed explanation of the Unified Soil Classification System is presented in MIL-STD-6198, 12 June 1968, entitled "Military Standard Unified Soil Classification System for Roads, Airfields, Embankments and Foundations"

ROUP	SYMBOL	ROCK CLASSIFICATION	GROUP	SYMBOL	ROCK CLASSIFICATION	KE	Y TO PH	IYSK	CAL PROPE
	0000	CONGLOMERATE			GNEISS	Bedding Characteristics		1 2 3	Massive Thin to medium Fissile
		SANDSTONE			SCHIST			4 5 6 7	Cross — bedded Foliated Platy Fragmental
	000	GRAYWACKE		1	QUARTZITE	Lithologic Characteristics	_	8 9 10	Clayey Shaly Calcareous Him Siliceous
		SILTSTONE	ROCKS	0.00 2.001 2.001	MARBLE			12 13 14 15	Sandy Salty Plastic seams Carbonaceous
	$\times \times $	INDURATED CLAY OR CLAYSTONE		חור יידעע אף את ול און נו קון יע א ני אני גי א	SOAPSTONE AND SERPENTINE	Hardness and Degree		16 17	Fossiliferous Ferruginous
		COMPACTION SHALE	METAMORPHIC		SLATE	of Cementation		18. 19 20.	Very soft or place Soft - Can be so Moderately hard with knife, of fingernail
		CEMENTED SHALE	<b>Σ</b>					21 22 23 24	Hard – Difficult i Very hard – Can Poorly cemented Cemented
		COAL				Texture		25 26	Dense Fine
	UMESTONE	LIMESTONE						27 28	Medium Coarse
OCKS	7, 7, 7,		l			Structure		29	Bedding a
ARY R	7,7,7	DOLOMITE						30 31 32 33.	Fractures scale Fractures close Brecciated isher Joints
SEDIMENTARY ROCKS	+ -+ -4 -+ -+ -4 -+ -+ -4	CHALK (OR MARL)			GRANITE			34 35	Faulted Sickensides
33				+ + + + + + + +	DIORITE	Degree of Weathering  Solution and Void  Conditions		36 37 38.	Unweathered Slightly weather Badly weathere
					GABBRO		_	39 40 41 42	Solid contains Vuggy (pitted) Vesicular Porous
			S)		RHYOLITE			43	Cavities Cavernous
			IS ROCK		ANDESITE	Swelling Properties		45 46	Non – swelling Swelling
			IGNEOUS ROCKS		BASALT (TRAP)	Slaking Properties		47 48 49	Non-slaking Slakes slowly or Slakes readily o
				130 140 130 140 170 140	TUFF OR TUFF BRECCIA				
		-	0	AGGLOMERATE FLOW BRECCIA					
Ī		<del>-</del>	ſ		-				

#### OF ROCKS KEY TO PHYSICAL PROPERTIES OF ROCKS Thin to medium bedded Fissile Cross — bedded Foliated Fragmental Clavev teristics. Shaly 10. Calcareous (limy) 12 Sandy 13 Sifty 14. 15. Plastic seams Carbonaceous Fossiliferous 17 Ferruginous Very soft or plastic 19 Soft - Can be scratched with fingernail Moderately hard -Can be scratched easily 20. with knife, cannot be scratched with fingernail Hard - Difficult to scratch with knife Very hard—Cannot be scratched with knife Poorly cemented 22. 23 25 Dense 26. Fine 28 Coarse 29 Bedding Gently dipping Steeply dipping Fractures, scattered Open 31 Fractures closely spaced 32. 33. 34. Brecciated isheared & fragmented) Cemented or tight Joints Faulted 35 Slickensides Unweathered 37 Slightly weathered 38. Badly weathered Solid, contains no voids Yuggy 'pitted 41 Vesicular Porous Cavernous 46 Swelling Non - slaking 48


49


Stakes readily on exposure

NOTE

WHILE THE BORINGS ARE REPRESENTATIVE OF SUB-SURFACE CONDITIONS AT THEIR RESPECTIVE LOCATIONS AND FOR THEIR RESPECTIVE VERTICAL REACHES, LOCAL MINOR VARIATIONS IN CHARACTERISTICS OF THE SUB-SURFACE MATERIALS OF THE REGION ARE ANTICIPATED AND. IF ENCOUNTERED, SUCH VARIATIONS WILL NOT BE CONSIDERED AS DIFFERING MATERIALLY WITHIN THE PURVIEW OF CLAUSE 4 OF THE CONTRACT

GROUND - WATER ELEVATIONS SHOWN ON BORING LOGS REPRESENT GROUND - WATER SURFACES ENCOUNTERED ON THE DATES SHOWN ABSENCE OF WATER SURFACE DATA ON CERTAIN BORINGS IMPLIES THAT NO GROUND—WATER DATA IS AVAILABLE. BUT DOES NOT NECESSARILY MEAN THAT GROUND WATER WILL NOT BE ENCOUNTERED AT THE LOCATIONS OR WITHIN THE VERTICAL REACHES OF THESE BORINGS





**OPERATIONS** 

## UNIT II

USERS GUIDE-AUTOMATED BORING LOG PROGRAM

## **PREFACE**

This User Guide and the associated programs were prepared by FTN Associates, Ltd., Little Rock, AR (FTN) for the Vicksburg District, Corps of Engineers (COE) under contract No. DACW38-88-D-0055, Delivery Order No. 3. The purpose of the work was to develop a system to allow the COE to incorporate boring log data into the Intergraph IGDS Design File format.

Program design and development was performed by Mr. Keith Nash (FTN) and Ms. Brenda Scott (FTN) under the supervision of Dr. Dennis Ford, PE (FTN). This User Guide was written by Keith Nash and Brenda Scott. The work was overseen by Mr. Eddie Templeton and Mr. Chris Dixon, Foundation and Materials Branch, COE.

This updated User Guide and associated programs were prepared by FTN for the Vicksburg District, COE under contract No. CACW38-90-P-1847 and supersedes the version dated 5 July 1989. The associated work involved modifications to scale denotation, symbolology, and text placement.

## TABLE OF CONTENTS

1.0	INTR	ODUCTION1-1
2.0	INSTA	ALLING BP2-1
	2.1	BP Executable Files2-1
	2.2	BP Seed File and Cell Library2-1
	2.3	Modifying the MicroStation User Environment2-1
	2.4	Additional Considerations
3.0	RUN	NING THE PROGRAM3-1
	3.1	Files
	3.2	Rows
	3.3	Pattern3-2
	3.4	Go3-2
	3.5	Quit
4.0	GRAF	PHIC FILES4-1
	4.1	Seed File4-1
	4.2	Cell Library4-1
	4.3	Drawing Files4-1
5.0		NTIAL PROBLEMS AND REMEDIES5-1
	5.1	Plate Size5-1
	5.2	Log Overlap5-1
	5.3	Error Codes
	5.4	Patterning5-4
ΛDI	PENDI	CES.
AL I		PENDIX A: Programmer's Guide
	~ (	CLANDON ON EUDPLAUBUREN CORDE

APPENDIX B: Input File Format

APPENDIX C: Controlling Plate Size

APPENDIX D: Cell Library APPENDIX E: Source Code

## 1.0 INTRODUCTION

BP (Boring log Plot/design file builder) is an Intergraph/Bentley Systems Inc. MicroStation utility developed to create design files containing boring logs. It uses as input the same ASCII data files used by the COE to generate CalComp plots on the Vicksburg District Harris 500 minicomputer. The main advantage of the system is that design files may be created and then modified interactively on PCs using the Intergraph MicroStation software. Once the information is arranged satisfactorily, a finished plot may be generated locally or from the COE IGDS VAX system (after uploading the design file).

## 2.0 INSTALLING BP

Installing BP is a straight-forward process involving: copying three executable files, copying a seed file and cell library, and modifying the MicroStation user environment. The following step-by-step instructions for each procedure assume the user has a basic understanding of DOS and MicroStation.

## 2.1 BP Executable Files

BP consists of three executable files: BP.EXE, BP\_TEXT.EXE, and BP\_PTRN.EXE. These three executable files must be located in a directory specified in the DOS PATH. A special directory for the programs may be created, or an existing directory (e.g., C:\BIN or C:\UTIL) may be used. Whichever approach is used, simply copy the three executable files into the desired directory and, if the directory is not already named in the DOS PATH, modify the AUTOEXEC.BAT so that it is.

## 2.2 BP Seed File and Cell Library

BP uses a seed file named BPSEED.DGN and a cell library named BPCELL.CEL. These two files should be copied into an appropriate directory (this directory's name will be needed in the next step).

## 2.3 Modifying the MicroStation User Environment

The BP programs make use of two MicroStation BSI environment variables: BP\_SEED and BP\_CELL. These environment variables must be set to give complete filename specifications for the BP seed and cell library files. MicroStation provides for such user environment variables by automatically loading whatever definitions it finds in the \USTATION\DATA\UCONFIG.DAT file. Thus the user need only modify this file to contain definitions for BP\_SEED and BP\_CELL.

As an example, suppose BPSEED.DGN and BPCELL.CEL are located in a directory named C:\USTATION\BP. Then the file named C:\USTATION\DATA\UCONFIG.DAT should be modified to contain the following lines:

BP\_SEED = C:\USTATION\BP\BPSEED.DGN
BP\_CELL = C:\USTATION\BP\BPCELL.CEL

Please note that the MicroStation environment may need to be enlarged to accommodate these variables. This may be done by using the MicroStation USCONFIG program, selecting "EDIT USER PREFERENCES", and increasing the environment table size. The maximum environment space needed by BP is approximately 150 bytes in addition to the MicroStation default environment table size.

## 2.4 Additional Considerations


As with all MicroStation utilities, the MicroStation resident system must be loaded before BP is executed. This may be done simply by running MicroStation before executing BP.

The BP system requires as much as 350 bytes of free space in the DOS environment. This space may be allocated by including an appropriate SHELL command in the CONFIG.SYS file. For example, the following SHELL command would allocate 1024 bytes of DOS environment space:

Users should be careful about loading Terminate-and-Stay-Resident software (such as SideKick) when using MicroStation and BP. TSRs use DOS memory even when they are dormant and this memory is thus unavailable to MicroStation and BP, both of which have large memory requirements. Trial and error is the only method of determining which TSRs may or may not be used successfully with MicroStation and BP.

## 3.0 RUNNING THE PROGRAM

**BP** is executed by entering BP at the DOS prompt. The following screen then appears:



Each of the menu choices (F, R, P, G, and Q) will be explained in detail later in this section.

## 3.1 Files

Pressing F causes BP to prompt the user for input data filenames and the desired design file name.

One data file is required for each row that will appear in the design file. BP will inform the user if a specified file does not exist and will continue to prompt for filenames until existing files are selected for all rows. Users may enter a DOS wildcard filename specification in lieu of an explicit filename. BP will then display a list of files matching the wildcard pattern and allow the user to select one from the list.

BP will construct a design file name composed of the row one data filename with a .DGN extension. The user may use this default name, or enter whatever name is desired for the design file.

If the number of rows has not been previously indicated, BP will prompt the user for this item before allowing the user to enter filenames (see Section 3.2

below).

## 3.2 Rows

This command allows the user to select the number of rows of logs that will appear in the design file. One, two, or three rows of logs may be selected. Each row requires its own input data file.

BP uses title block and note text from the row one data file when more than one row of logs is requested.

## 3.3 Pattern

This command can be used to 'toggle' soil symbology patterning on and off. Turning off patterning considerably reduces the execution time of BP and is useful in determining whether the design file layout is correct. Simply press P to toggle patterning on and off.

## 3.4 Go

Pressing G begins processing with the number of rows and the data files specified. The BP\_TEXT and BP\_PTRN programs are automatically called to place the text and perform the patterning dictated by the specified data file(s).

If the number of rows has not been specified, BP will first prompt the user for this item (just as if the user had entered R). Similarly, if no input files have been defined, BP will prompt the user for this information (just as if the user had entered F).

BP writes plate size and log placement information, as well as any errors encountered, to a log file named BP.LOG.

## 3.5 Quit

Pressing Q causes BP to end execution and return to the DOS prompt.

### 4.0 GRAPHIC FILES

## 4.1 Seed File

BP was designed to work with the seed drawing file BPSEED.DGN. This seed file must be located in the directory specified by the environment variable BP\_SEED. BPSEED.DGN was created with master units in square feet, sub-units of 10 inches and positional units of 1000.

## 4.2 Cell Library

BP utilizes a cell library containing symbols for patterning the plotted core boring logs. This cell library, named BPCELL.CEL, must be located in the directory specified by the environment variable BP\_CELL. All cells were created using the Unified Soil Classification symbology supplied by the District. Pattern cells were created on level 1 using a 1 x 1 master unit area to ensure proper repeatability. Cells, cell names and descriptions are shown in Appendix D.

## 4.3 Drawing Files

BP creates the boring log design file using BPSEED.DGN and places it in the directory from which BP was invoked. Text is placed using fonts 1 and 3 with weights of two.

The element description, level and text size appear below.

Level	<u>Text Si</u> <u>Height</u>	ize <u>Width</u>	Description
1	0.072	0.06	Boring log shape, patterning, major modifications
2	0.072	0.06	Consistency and modification
3	0.096	0.08	text Log descriptions and associated tic marks
4	0.072	0.06	Color text and dimension lines
4 5	0.096	0.08	Plastic and liquid limits, D10 and water content data and titles
6	0.20 0.15	0.20 0.15	Individual log identifications Log location, field book, date

Level	<u>Text S</u> <u>Height</u>	ize Width	Description
7	0.20	0.10	Ground surface elevation, tic marks along logs corresponding to staff increments
8	0.01	0.08	Tertiary depth and water table
9	0.01	0.08	Unified compression test and penetration resistance
10	0.12	0.12	Notes
60	0.15	0.15	Vertical staffs
61	0.15	0.15	Horizontal staffs
62	vari	es	Border and title block

#### 5.0 POTENTIAL PROBLEMS AND REMEDIES

Most errors encountered in running BP have to do with log placement or plate size. These errors can usually be corrected by modifying the input file(s).

Each time BP is invoked, it writes a design file layout summary and any error information to a log file named BP.LOG. This file may be examined for detailed information about the placement of logs and as an aid in determining the cause of any detected errors.

## 5.1 Plate Size

BP uses the X and Y-axis ranges and scales specified in the data file to calculate the plate size. The X-axis size is determined by subtracting Xmin from Xmax, dividing the result by the X-axis scale factor, and adding a constant to allow for left and right margins. Similarly, the Y-axis size is determined by subtracting Ymin from Ymax, dividing the result by the Y-axis scale factor, and adding a constant to allow for margins at the top and bottom of the plate. Both calculations yield the number of Master Units necessary to place data at the desired scale (e.g., 1 inch = 50 feet). All calculations assume that 1 master unit is equal to 1 inch.

The maximum plate size allowed is 36" x 48" (ANSI 'E' size). If the calculated plate size exceeds these limits an error is returned and the user may choose either to abort the run or to continue with the larger plate size.

Users can control the plate size by adjusting the axis scale and/or the axis ranges. For examples of this procedure, see Appendix C.

## 5.2 Log Overlap

Errors occur when logs are too close together or when a boring log overwrites the title block. In either case the user may continue the run and edit the design file, or abort the run and change the offending log's horizontal coordinate by editing the appropriate input file.

## 5.3 Error Codes

The following error codes are returned by the BP program.

Error Code	Description
-1	Error invoking child process
5	Disk full
10	Video error
20	Environment variable BP_DGN not found
21	Environment variable BP_CEL not found
<b>2</b> 2	Environment variable BP_DAT not found
30	Unable to open log file
31	Unable to open sector/offset log file
32 33	Unable to open work file
33 34	Design file does not exist
35	Cell library does not exist Unable to open design file
36	Unable to open input file
37 37	Error reading global data
38	Error buffering log to work file
40	Unable to size plot
50	Unable to place border and title block
51	Unable to place notes
52	Unable to place vertical axis
53	Unable to place horizontal axis
61	Error reading major modifications(text)
	Error reading strata (pattern)
62	Unable to place major
	modifications (text)
	Error placing log shape (pattern)
63	Error reading horizontal line depths
64	Unable to place horizontal lines
65	Error reading descriptive text
66 67	Unable to place descriptive text
67 68	Error reading colors
69	Unable to place colors Error reading D10 and water content
70	Unable to place D10 and water content
71	Error reading liquid and plastic limits
72	Unable to place liquid and plastic
<i>1 1</i>	limits
73	Error reading penetration resistance
, 0	and UCT
74	Unable to place penetration resistance
	and UCT
75	Error reading consistency and
	modifications
76	Unable to place consistency and
, 0	Contains to prince entitlemental und

	modifications
77	Unable to place incremental tic marks
78	Unable to place tertiary data
79	Unable to place individual log IDs
80	Unable to place individual log staffs

Error codes of 900 or greater are returned by MicroStation Customer Support Library (CSL) routines. These errors will cause the BP program to abort and an error message will be written to the log file (BP.LOG). Possible CSL errors are listed below.

Error Code	Description
904	Too few vertices in placing shape
905	Too many vertices in placing shape
925	Could not establish message queue
926	Could not get response from
	MicroStation
929	Not a valid TCB variable
930	Error converting to Radix-50 value
933	Illegal element definition
934	Illegal element format
936	Resident scanner not loaded
938	No cell library attached
939	Cell is not in cell library
940	Cell nesting error
941	Invalid cell or cell library
947	Invalid open type
948	Unable to open design file
949	Unable to open cell library
951	Security device not installed
952	'UCMVARS.DAT' or 'USTATION.RSC not
	found
960	Design file disk is full

## 5.4 Patterning

Boring log patterning is accomplished using cells found in BPCELL.CEL. Cells can be edited or created without causing errors, if the following steps are taken:

- 1. Always work in a drawing file that was created using BPSEED.DGN.
- 2. If editing an existing cell, always place the cell at an active scale of 1. This ensures the patterning will be placed at the proper spacing when running the program.
- 3. After an existing cell is placed, use the drop element command. This will prevent nesting errors while using BP.
- 4. Place the fence 1 master unit by 1 master unit when creating the cell.
- 5. Pattern cell names are limited to 3 characters.
- 6. Pattern cells must be created on level 1 to ensure proper patterning.

APPENDIX A: Programmer's Guide

## Programmer's Guide

The BP system is composed of three "C" programs and 43 FORTRAN subroutines. FORTRAN was used for a majority of the coding in order to facilitate porting the program to the VAX environment. "C" was used for the PC version because of its ability to spawn child programs and to provide a user-friendly interface.

BP.EXE, the main routine, is a shell that prompts the user for the number of rows, the data files for each row, and the design file. It also queries the MicroStation environment for the BP\_SEED and BP\_CELL variables, which give complete paths to the seed file and soil symbology cell library. All this information is communicated to the two child programs via the environment. BP.EXE then calls the child program BP\_TEXT.EXE, which places text, followed by the BP\_PTRN.EXE program, which does the patterning.

This approach of using a small parent to call two larger children was necessitated by memory model limitations imposed by the MicroStation Customer Support Library (CSL). The CSL uses the Medium memory model (i.e., unlimited code segments, one 64 kByte data segment). CSL programs must be linked with large stacks (16-32 kBytes) and this stack space is allocated from the default data segment, of which only one is available. This imposes a severe limitation of less than 32 kBytes of available user data space in the default data segment. Unfortunately, the CSL patterning routine alone uses nearly all of this available space. It was thus decided to break the program up into a main parent and two child processes, each of which would have its own data segment. In addition, overlay techniques were used with BP\_PTRN.EXE in order to reduce the total load size of the program.

Modifying the BP programs requires the following items:

- 1) MicroSoft "C" version 5.1
- 2) MicroSoft FORTRAN version 4.1
- 3) MicroSoft LINK version 5.01.20
- 4) MicroSoft MAKE (any version)
- 5) Intergraph MicroStation Customer Support Library version 3.0 (MICROCSL.LIB)

- 6) The FTN Utility Library and header files (MCUTIL7.LIB, CUTIL.H, SBUF.H)
- 7) The BP MAKE file (BP.MK)
- 8) The BP\_PTRN link response file (BP\_PTRN.NMS)
- 9) The BP FORTRAN source files (\*.FOR and \*.INC)
- 10) The BP "C" source files (BP\*.C and BP.H)

The BP programs may then be re-compiled and re-linked with the BP.MK MAKE script using the following command line:

## MAKE BP.MK

MAKE will compile any object files whose source files have been modified, update the object library BORPLT, and link the executable files BP.EXE, BP\_TEXT.EXE, and BP\_PTRN.EXE

APPENDIX B: Input File Format

****	File Header				
Record	Field	Columns	Range	Format	Description
1	1	(1-5)	-1 1	15	Vertical staff to left of each log (Depth in Feet) Two vertical staffs, lt of first boring & rt of last
	2	(6-10)	·1 1	15	Horizontal staff w/ Distance in Feet No horizontal staff
	3	(11-15)	·1 1 -2	15	All staffs omitted Left & right vertical staff plotted Scale across top & +00 for stations
	4	(16-20)	-1 1 -2	15	No mods or written descriptions Mods and written descriptions No written descriptions, permits log overlap(?)
	5	(21-25)	-1 1	15	"DEPTH IN FEET" plotted next to vertical staffs "ELEVATION IN FEET MSL" plotted next to vertical staffs
	6	(26-30)	-1 1	15	Written descriptions in upper case Written descriptions in lower case
	7	(31-35)	-1 1 2	15	15" H x 25" W plate size 19" H x 28" W plate size 22" H x 37" W plate size
	8	(36-40)	*		No. of lines of notes (??)
	9	(41-45)	(alway	rs 1)	( ????? )
3-5 6 7-8 9-12	1 2 3 4 5 6 7	( 1-10) (11-15) (16-20) (21-25) (26-30) (31-35) (36-40)		RJ,F . 15 15 F5.1 F5.1 15 15 CENTER	Maximum distance in feet Lower vertical staff elevation Upper vertical staff elevation Vertical scale Horizontal scale Size of plate factor No. of boring logs Title cards (max of 38 characters) Title cards (max of 19 characters) Title cards (max of 45 characters) Notes (max of 45 char) plot next to title block
****	Boring Header	Logs			
1	1 2	(1-10) (11-20)		F10.2 F10.2	X-dist from horizontal staff origin Vertical staff or ground surface elevation
2	1 2				Log ID (max=20 char) plotted above borings tertiary depth
3-4	1				Location cards
5	1				Field Book number
6	3	(23-29) (32-36)			Sample date, (mwt_date) water table date, mo,day,yr (mwt_depth) water table depth
***** Lo	og data	formet			
7-end	1	( 1- 5)		F5.1	(sfrom) Upper depth of sample (First log sample must be 0.0)
	2	( 6-10)		F5.1	(sto) Lower depth of sample
	3	(11-13)		13	(Water_cont) Water content (% dry weight) (# of add tl cards if

## Page 2 of LAYOUT, Mon Jul 16 16:08:15 1990

	4	(14-18)	F5.1	(strat_chg) Stratum change
	5	(19-20)	A2	(sym) Main class (CH,SM,PT)(NS=no sample)
	6	(21-22)	A2	(rock1) Usually blank - RO indicates special case
	7	(23-25)	£A	(rock2) Major modifications (SIS,SS,O,F,M,C) (centered)
	8	(26-28)	A3	(consis) Consistency
	9	(29-37)	3A3	(color1,2,3) Colors of sample
	10	(38-51)	3A3,A5(ct	r)(msym1,2,3,4) Modification symbols
	11	(52-55)	14	(tblows_ft) Penetration resistance (blows/ft)
	12	(56-59)	14	(uct) Unconfined compression test
	13	(60-62)	3x	Blank
	14	(63-65)	A3	(atlim_(l) Liquid limit
	15	(66-68)	Æ	(atlim_pl) Plastic limit
	16	(69-73)	F5.4	(d10_size) D10 size in millimeters
	17	(74-76)	A3	(twat_cont) Water content
	18	(77-80)	A3	(second_uct) Second unconfined compression test
****	For r	ock1=RO cor	ntinuation records	s:
???	1	( 1-25)	25X	Blank
	???	(26-51)		Written description (may be more than 1 record) (consis,color1,color2,color3,msym1,msym2,msym3,msym4)
LAST		( 1- 5)	999.9	End of log indicator record

APPENDIX C: Controlling Plate Size BP uses the minimum and maximum axis values (in feet) and the axis scale factor (in feet per inch) to determine the size of each axis. The axis size (in inches) is obtained by subtracting the minimum value from the maximum value and dividing by the scale factor. A constant is added to the result to allow for the left and right margins on the X-axis and the top and bottom margins on the Y-axis. These margins are 4.5 inches on the X-axis and 2.5 inches on the Y-axis, so 9.0 inches is added to the calculated X-axis size and 5.0 inches is added to the calculated Y-axis size. In addition, a constant 3.4 inches is added to the Y-axis size to allow for placement of the log IDs. This additional constant is added for each row of logs on the plate. If more than one row of logs appears on a plate, the row yielding the largest X-axis size determines the X-axis size of the plate.

## Example:

Given a data set with a Y-axis range of 0 to 90 feet and a Y-axis scale factor of 10 feet per inch, calculate a new range yielding a plate which is as close as possible to 21 inches in length along the Y-axis.

Plate size using the original range:

$$Ys = (90 - 0)/10 + 8.4 = 17.4$$
 inches

Solving for the necessary range:

$$Ymax - Ymin = Ysf * (Ys - K) = 10 * (21 - 8.4) = 126$$

Using a range (Ymin, Ymax) of (0,130) gives a plate size of 13+8.4=21.4 inches.

APPENDIX D: Cell Library

CELL L	IBRARY	- BPCELL
CELL	CELL NAME	DESCRIPTION
//	СН	FAT CLAY
///	CL	LEAN CLAY
1/2	GC	CLAYEY GRAVEL
1-1	GM	SILTY GRAVEL
••	GP	SANDY GRAVEL
 	GW	WELL GRADED GRAVEL
	мн	INORGANIC SILT
	ML	SILT
//	ОН	ORGANIC CLAY
1 1	OL	ORGANIC SILT
**************************************	PT	PEAT
7/2	SC	CLAYEY SAND
o   o   o   o	SM	SILTY SAND
:::	SP	POORLY GRADED SAND
° ° ° ° ° ° ° ° ° ° ° ° ° ° ° ° ° ° °	SW	WELL GRADED SAND
	WD	WOOD

CELL L	IBRARY	- BPCELL
CELL	CELL NAME	DESCRIPTION
	AGG	AGGLOMERATE FLOW BRECCIA
	AND	ANDESITE
11.1.11. 11.1.1.1. 11.1.1.1.1.1.1.1.1.1	BAS	BASALT TRAP
	СЕМ	CEMENTED SHALE
121	CHA	CHALK OR MARL
x x x x x x x x x	CLA	CLAYSTONE
	COA	COAL
,.o., ,.o., ,.o.,	CON	CONGLOMERATE
+++ ++ +++	DIO	DiORITE
姜	DOL	DOLOMITE
華	LIM	LIMESTONE
<b>第</b>	GAB	GABBRO
K	GNE	GNEISS
4. b.	GRA	GRAYACKE
菜	GRN	GRANITE
\$ • \$ \$ \$ \$ \$ \$ \$ \$ \$	MAR	MARBLE

CFILL	IDDADV	- BPCF!!
CELL	BRARY  CELL NAME	DESCRIPTION
	CELL NAIVIE	DESCRIPTION
\$ 14 f	QUA	QUARTZITE
25 A	RHY	RHYOLITE
***	SAN	SANDSTONE
	SCH	SCHIST
	SHA	COMPACTION SHALE
	SIL	SILTSTONE
***	SLA	SLATE
# 1# 1/6 0,	SOA	SOAPSTONE & SERPENTINE
	TUF	TUFF OR TUFF BRECCIA
	ARROW	DIMENSION ARROW
$\Box$	WTRTB	WATER TABLE SYMBOL

## UNIT III

CELL LIBRARY AND MATRIX MENU

#### Geotechnical Matrix Menu Installation Instructions

Two high density disks containing the geotechnical matrix menu, associated cell libraries and other files are enclosed. The following is a brief description of the contents of each disk along with general instructions concerning setup and configuration.

<u>Disk #1. Cell Libraries:</u> Five files are included on this disk; G3GEO.CEL, the master cell library, G3SYSTEM.CEL, the Seattle System cell library which is attached and used in conjunction with the AM=G3MENU,SB\_ side bar menu located along the right edge of the menu, MSMENU.CEL, the cell library which contains the menu cell (see discussion below), and two CDX files, each associated with the matching cell libraries.

The G35YSTEM.CEL and .CDX files, containing the Seattle District master system cell library, may not be usable for all districts since each district using Intergraph may already have their own master system cell library. However, it is included and used in conjunction with the G3MENU side bar menu. The MSMENU.CEL and .CDX files are usable if the district receiving this set of floppies has not created their own menus. However, if in doubt it is safer to follow the instructions below explaining how to add a new menu cell to their own system.

The files G3GEO.CEL, G35YSTEM.CEL, and G35YSTEM.CDX should be located in the "cel" subdirectory. MSMENU.CEL and MSMENU.CDX are normally located in the "data" subdirectory. Please note that locations for all the files can be changed or adapted to your system simply by reconfiguring Microstation. The menus are accessed by using the Microstation ATTACH MENU (AM=) and ATTACH LIBRARY (RC=) commands.

<u>Disk #2:</u> This disk contains three subdirectories (DGN, UCM, and SBM). The subdirectory DGN contains G3GEOMM.DGN which is the design file which contains the menu. This file should be placed in the "dgn" subdirectory. As stated above, if no other menus have been attached to MSMENU.CEL then G3GEOMM.DGN is only needed to make copies of menus and to make future changes in the menu itself. However, it is safer to create your own cell of the menu so your copy of MSMENU.CEL is maintained.

Four levels are used in G3GEOMM.DGN; levels 1-3 and level 63. Levels 1-3 contain everything you see on your copy of the menu. Level 63 contains the information that the system needs to be able to read the menu. In order to create the cell first temporarily reconfigure Microstation so that cell libraries are located in the "data" subdirectory then attach MSMENU.CEL (RC=MSMENU); you may have to reboot first. Change the active level to 63 and turn off levels 1-62 (LV=63, OF=1-62). Fence all the text in the file, including the text node at the top, define the origin as the lower left hand corner, and create the cell (CC=G3GEO,geotech matrix menu,m). The information between the commas is merely a description and the m designates the cell as a matrix menu. Reconfigure Microstation so that cell libraries are located in the "cel" subdirectory and reboot.

The subdirectory UCM contains all user commands accessed by menu. Contents of disk should be copied into the "ucm" subdirectory.

The side bar menus are contained in the subdirectory SBM. These menus are accessed from menus or by keyins. GT is the menu which is the side bar version of the geotech menu. This menu could be used with a mouse, without a digitizer tablet. Seattle places these files in a "sb" subdirectory under the "ustation" directory; but they could go anywhere just so the Microstation configuration matches.

There are a few commands that don't work yet, such as the raster and stop drawing commands. These are not supported by Microstation yet, but they did work on the Vax based Intergraph. The menu can be modified simply by editing the text on level 63 of G3GEOMM.DGN and recreating the cell. Modifying the graphics on levels 1-3 changes the paper menu appearance. See Chapter 18 in the Microstation manual for more information on matrix menus. The G3 designation in many of the filenames relates to Seattle District; other districts have other designations. Files and menu commands can be edited if necessary.